

Elo Touch Solutions Technical Support

Online self-help:

www.support.elotouch.com

North America 800-ELO-TOUCH Tel +1 408 597 8000 Fax +1 408 597 8050 EloSales.NA@elotouch.com

Europe Tel +32 (0)16 70 45 00 Fax +32 (0)16 70 45 49 elosales@elotouch.com

Asia-Pacific Tel +86 (21) 3329 1385 Fax +86 (21) 3329 1400 EloAsia@elotouch.com

Tel 786-923-0251 Fax 305-931-0124 EloSales.LATAM@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elio Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates







www.elotouch.com

Quick Installation Guide

Rear Facing Display Mount E-Series AiO Touchcomputer


Revision B P/N E134672

© 2017 Elo Touch Solutions, Inc. All rights reserved. ISO 9001

Installation



Remove the mounting screw covers from the back of the AiO and attach the bracket using the 4 screws included with the kit.



Mount the display bracket to the back of the rear facing display using the 75mm x 75mm VESA mounting holes



Hook the rear facing display bracket onto the AiO bracket and secure using 1 M3 screw (included in the kit) on either the top or bottom (marked by green arrows) of the bracket.